


NOTES:

- 1. LOCATE HANDHOLE AS DIRECTED BY C.O.B. ELECTRIC UTILITY.
- 2. INSTALL A MINIMUM 8" OF 3/4" CRUSHED ROCK UNDER HANDHOLE.
- 3. THIS HANDHOLE CAN ONLY BE INSTALLED UNDER TRANSFORMER PAD PER SD #600-61.

APPROVED:

REF: 1730-18



PLASTIC HANDHOLE, 17"x30"



STANDARD DRAWINGS

600-43